


Sliding-Pivot Retractable Glass Doors

To stack the doors to the right, the main door will be situated on the right. The door will pivot open to the right (inwards or outwards), then each door can slide individually towards the first door and pivot open to rest against the preceding door, until all doors are stacked on the right. Similarly, to stack doors to the left, the main door will be situated on the left (doors can open inwards or outwards).



Sliding-pivot doors may also be spaced across the opening.

